

■ Mechanical Drawings :



■ LED Indicators:



RA-3048 LED indications:

- "Power" (green color) indicates if the module is ON or OFF
- "Warning" (yellow color) indicates an abnormal situation
- "Alarm" (red color) indicates an alarm situation

LED	Status	Description	
Power (Green)	ON	Module is powered up normally	
	OFF	Mains are unavailable	
Warning (Yellow)	Flashing	<ul style="list-style-type: none"> ■ Rectifier in power derate mode ■ Input voltage out of range, flashing at overvoltage ■ flashing at high voltage ■ flashing at low voltage ■ flashing at overvoltage ■ flashing at high temperature ■ flashing at power limit ■ flashing at current limit ■ flashing at fan failure 	
		ON	Rectifier adopts Equalize
		OFF	No abnormal situation is present
Alarm (Red)		ON	<ul style="list-style-type: none"> ■ Module is in Shut-down Mode due to low mains, high internal temperature, or high output voltage ■ Internal module failure (malfunction) ■ Fan failure (single or double fan malfunction)
			OFF